

Handwritten:

*The following policy shall apply to the blocking of expansion joint devices.*

*The detail showing plates or angles tack welded to the top flange shall be used unless the contractor plans to use the longitudinal strike-off and specifically request the other method of blocking.*

*The first blocking shall be within 2 feet of the end of the channel. The maximum spacing of the blocking shall be approx 8 feet.*

*For shipping purposes it will probably be necessary to place straps on bottom flange.*

*If any blocking is used between webs it shall be timber rather than steel plates.*